

# **GEOMATICS ENGINEERING**

## **(Advanced Surveying)**

### Theodolite Surveying - Part I

**KIRAN S R**

Lecturer in Civil Engineering

Government Polytechnic College

DEPARTMENT OF TECHNICAL EDUCATION

Government of Kerala

- 1 Introduction
- 2 Study of Transit-Vernier Theodolites
- 3 Applications of Theodolite

# Introduction

## What is Theodolite?

KIRAN S R

- It is an optical instrument used in Surveying.



# Introduction

## What is Theodolite?

- It is an optical instrument used in Surveying.
- **Purpose:**

KIRAN S R

# Introduction

## What is Theodolite?

- It is an optical instrument used in Surveying.
- **Purpose:**  
Measurement of **Horizontal** as well as **Vertical angles**.

# Introduction


## What is Theodolite?

- It is an optical instrument used in Surveying.
- **Purpose:**  
Measurement of **Horizontal** as well as **Vertical** angles.
- **Unit of Measurement:**



# Introduction

## Units for Angular Measurement:




## Conversion of Units

- **Degrees ( $^{\circ}$ ):**  $1^{\circ} = \frac{\pi}{180}$  radians
- **Minutes ( $'$ ):**  $1' = \frac{1^{\circ}}{60}$
- **Seconds ( $''$ ):**  $1'' = \frac{1'}{60}$

# Introduction

## Evolution of Theodolites:



**Everest Theodolite**



**Plain Theodolite**



**Transit Vernier Theodolite**



**Repeating Theodolite**



**Directional Theodolite**



**Electronic Theodolite**



# Introduction

## Classification of Theodolites:


- Based on the precision of Graduated circles (Horizontal & Vertical Circles).

### ① Vernier Theodolite

- Graduated Circles use Verniers for angular measurements.
- Generally, Least count = 20"


### ② Micrometer Theodolite or Micro-optical Theodolite

- More precise than Vernier Theodolites.
- Graduated circles use a micrometre and a direct-angle-reading-microscope.
- Generally, Least count = 1".



Reading shown = 331 30'  
+  
24'  
= 331 54'

VERNIER-TYPE  
GRADUATION



Reading shown = 90° 20'  
+  
5' 6"  
= 90° 25' 6"

MICROMETER-TYPE  
GRADUATION



### Classification of Theodolites:

- Based on Measurement of Horizontal angles

## ① Repeating Theodolite

- It has 2 vertical axes (similar to double-spindle arrangement of Transit Theodolites).
- It measures a horizontal angle by repeated observation of angles at different settings on the horizontal circle, and then dividing the total angle by the number of observations.
- Horizontal and vertical circles can be viewed and read simultaneously through the reading microscope.

## 2 Directional Theodolite

- It has 1 vertical axis only  $\therefore$  Horizontal circle is fixed.
- It measures directions, instead of angles. Hence, an angle between the lines can be found by subtracting the first direction from the second.
- Each observation shall be the mean of readings on diametrically opposite sides of the circle (similar to A & B verniers of Transit Theodolites).

# Introduction

## Classification of Theodolites:

- Based on Construction

### ① Optical-Mechanical Theodolite

- Observations are taken manually by reading from Graduated circles.
- All operations for setting and orientation are manual.

### ② Electronic-Digital Theodolite

- Provides the value of observation directly on the digital viewing panel.
- Comprises a mechanism for automatic instrument orientation.
- Consist of a Electronic Data collectors, Keyboard and Digital Panel.
- Can be interfaced with Computers for data transfer.

# Introduction

### Classification of Theodolites:

In this course, we shall confine our discussions to

**Transit-Vernier Theodolites**



and

**Electronic Theodolites**



# Transit-Vernier Theodolites


### Parts of a Transit-Vernier Theodolite:



A theodolite with its primary components disassembled

# Transit-Vernier Theodolites

## Parts of a Transit-Vernier Theodolite:



# Transit-Vernier Theodolites


## Parts of a Transit-Vernier Theodolite:

### 1 Telescope:

- Used to sight the object.
- Consists of eye-piece, object glass and focusing screw.
- Mounted on horizontal axis.

### 2 Vertical Circle:

- Used to measure vertical angles.
- Rigidly attached to telescope (i.e., it rotates with the telescope).
- Graduated, either from  $0-360^{\circ}$  or divided into 4 quadrants (measuring  $0-90^{\circ}$ ).



14/53

15/53




# Transit-Vernier Theodolites

## Parts of a Transit-Vernier Theodolite:

### 5 Spindles:

- conical arrangements to which upper & lower plates are separately fixed.
- Inner spindle  $\Rightarrow$  carries upper plate (carries verniers).
- Outer spindle  $\Rightarrow$  carries lower plate (carries main circular scale).



# Transit-Vernier Theodolites


### Parts of a Transit-Vernier Theodolite:

**6 Lower Plate:**

- Attached to outer spindle.
- Carries main circular scale for horizontal angle measurements.  
Therefore, lower plate is also called Scale plate.
- Consists of lower clamp screw (for fixing) and tangent screw (for fine adjustment)

⑦ **Upper Plate:**

- Carries two vernier scales at diametrically opposite points.
- Supports A-Frame.
- Consists an upper clamp screw and tangent screws.





# Relevant Terminologies

- ① **Swinging the Telescope:** means to rotate the telescope about its vertical axis in the horizontal plane. A swing is called right or left according as the telescope is rotated clockwise or counter clockwise.
- If the telescope is rotated clockwise  $\Rightarrow$  Right swing
  - If the telescope is rotated anticlockwise  $\Rightarrow$  Left swing




Figure: Swinging the Telescope (Plan View)

# Relevant Terminologies



- ② **Transiting the theodolite:** means rotating the telescope in the vertical plane, through  $180^\circ$ . Since Line of sight is reversed in this operation, it is also called “**Reversing**” or “**Plunging**”.



Figure: Transiting the Telescope (Side View)

# Relevant Terminologies


- 3 **Horizontal axis (Trunnion axis):** is the axis about which the telescope transits.
- 4 **Vertical axis:** is the axis about which upper & lower plates rotate.
- 5 **Face Left:** If face of the vertical circle is to the left side of observer, then such observation of the angles is known as face left observation.
- 6 **Face Right:** If the face of the vertical circle is to the right side of observer, then such observation of the angles is known as face right observation.





- **Telescope normal:** when
  - the face of vertical circle is to the left of observer, and
  - sighting vane or the bubble of telescope is above the telescope.

- Telescope inverted:** when
- the face of vertical circle is to the right of observer, and
  - sighting vane or the bubble of telescope is below the telescope.







- These are a set of operations which are performed on a theodolite to make it ready for taking observations.
- The adjustments to be made at every setting of the instrument.
- It includes the following steps:
  - 1 Setting up the theodolite over a station.
  - 2 Leveling up.
  - 3 Elimination of parallax.

# Temporary Adjustments of a Theodolite

## ① Setting Up: It includes two operations:

- Centering a theodolite over a station: Done by means of a plumb bob.
- Approximately leveling it by tripod legs only: Done by moving tripod legs radially or circumferentially.



### RADIAL MOVEMENT OF LEG



- a) Shifts the plumb bob radially in the direction of the leg.  
b) Does not affect the level status of the instrument appreciably.  
=> This operation enables to centre the instrument over the given station point.


### CIRCUMFERENTIAL MOVEMENT OF LEG



- a) Does not appreciably shift the plumb.  
b) Tilts the instrument and affects the level of the plate bubbles.  
=> This operation enables approximate levelling of the instrument without shifting it off the station point.

# Temporary Adjustments of a Theodolite

- ② **Leveling Up:** Here, accurate leveling is performed with the help of foot screws with reference to the plate levels, so that the vertical axis shall be truly vertical. Procedure is as follows:
- Turn the upper plate until the longitudinal axis of the plate level is roughly parallel to a line joining any two of the leveling screws (A & B).
  - Hold these two leveling screws between the thumb and first finger of each hand uniformly so that the thumb moves either towards each other or away from each other until the bubble comes to the center.



## 2 Leveling Up (Procedure Contd...):

- 

- ◀ ◻ ▶ ◀ ◻ ▶ ◀ ≡ ▶ ◀ ≡ ▶ ≡ ▶ ↺ 🔍 ↻

### ③ Elimination Of Parallax:

-


### ③ Elimination Of Parallax:

- 
- The figure consists of two circular panels side-by-side. Both panels show a perspective view of a road with a yellow center line receding into the distance. On the horizon, a hot air balloon with orange and red stripes is visible against a clear blue sky. The left panel is heavily blurred, while the right panel is in sharp focus.

## Permanent Adjustments of a Theodolite

## What are Fundamental Lines of a Theodolite?

- 1 Horizontal axis (or Trunnion axis)
- 2 Vertical axis
- 3 Line of Sight (or Line of collimation)
- 4 Axis of plate level
- 5 Axis of altitude level



31/53




### Permanent Adjustments of a Theodolite:

- 
- A detailed diagram of a transit instrument, showing its various components and axes. The instrument is mounted on a base with a horizontal circle. A vertical circle is attached to the base, and a trunnion axis is shown. The vertical axis is also indicated. The line of sight is shown passing through the telescope. The axis of the plate level is also shown.
- Labels in the diagram include:
- vertical axis
  - line of sight
  - Vertical circle
  - trunnion axis
  - Horizontal circle
  - Axis of Plate Level




# How to read angles in a Transit-Vernier Theodolite?

Angles are read from Horizontal and Vertical circles in the following manner:



# Accurate measurement of Angles


- Theodolites shall never perfectly obey the relations between its fundamental lines. Hence, Perfectly-adjusted Theodolites are hypothetical, and therefore, contribute to errors in measurement of angles.
- To eradicate such errors, an angle is measured in 2 modes using theodolite as:
  - 1 Face Left, Right Swing mode, AND
  - 2 Face Right, Left Swing mode.
- The average of the above modes give better results.



Plan View

# Accurate measurement of Angles


- To measure the included angle  $\angle POQ$  (see figure),
  - 1 The instrument set at point O sights point P first in **Face Left** position, which is then **swung Right** towards B and bisecting the same. Horizontal circle readings at P & Q are noted.
  - 2 The telescope is now transited to **Face Right** position. Without changing the angle, Q is sighted first and is then **swung Left** to bisect P. Horizontal circle readings noted again.
  - 3 Angles observed in both modes are averaged and then the included angle determined as = Reading at Q – Reading at P



Plan View

# Accurate measurement of Angles

- Note that,
  - In Right Swing, the reading on the Horizontal circle increases.
  - In Left Swing, the reading on the Horizontal circle decreases.





## Applications of Theodolite

**(i) Measurement of Horizontal Angles:** Horizontal angle is measured by any of the following two methods.

- 1 Repetition Method
- 2 Reiteration Method



# Applications of Theodolite

## (i) Measurement of Horizontal Angles:


### ① Repetition Method

- used for measurement of horizontal angles with high accuracy.
- here, the same angle is measured repeatedly and averaged.
- Generally, an angle is measured 3 times in Telescope normal condition and 3 times in Telescope inverted condition.

**(i) Measurement of Horizontal Angles:**

## 1 Repetition Method

- Set up the instrument over 'O' and level it accurately.
- With the help of upper clamp and tangent screw, set  $0^\circ$  reading on vernier 'A'. Note the reading of vernier 'B'.
- At Face Left, release the lower clamp and direct the telescope approximately towards the point 'P'. Tighten the lower clamp and bisect point 'P' accurately by lower tangent screw.




# Applications of Theodolite

## (i) Measurement of Horizontal Angles:

### ① Repetition Method

#### Procedure: (Contd...)


- Release the upper clamp and turn the instrument clock-wise (swing right) towards Q. Clamp the upper clamp and bisect 'Q' accurately with the upper tangent screw. Note the readings of verniers 'A' and 'B' to get the values of the angle POQ.
- Release the lower clamp and turn the telescope clockwise to sight P again. Release the upper clamp, turn the telescope clockwise and sight Q.



**(i) Measurement of Horizontal Angles:**

## 1 Repetition Method

- Repeat the process until the angle is measured 3 times. The Final Horizontal circle reading =  $\theta_1 + \theta_2 + \theta_3$
- The mean angle with Face Left =  $\left( \frac{\text{Final Horizontal Circle Reading}}{3} \right)$ .
- Change face and make similar observations by Left swing.
- The average horizontal angle is then obtained by taking the average of the two angles with face left and face right.



# Applications of Theodolite

## (i) Measurement of Horizontal Angles:

### ① Repetition Method

A sample observation table:

Instrument At	Sighted to	Face : Left									Swing : Right				Face : Right									Swing : Right				Average Horizontal Angle				
		A			B			Mean			No. of Repetitions	Horizontal Angle			A			B			Mean			No. of Repetitions	Horizontal Angle							
		°	'	"	°	'	"	°	'	"		°	'	"	°	'	"	°	'	"	°	'	"		°	'	"					
		Q	P	0	0	0	0	0	0	0		0	0	1				0	0	0	0	0	0		0	0	0	1				
	R	52	41	20	41	20	52	41	20	52					52	41	40	41	40	52	41	40										
	R	158	04	40	04	40	158	04	40	40	3	52	41	33	158	04	40	04	40	158	04	40	3	52	41	33	52	41	33			

## Applications of Theodolite

**(i) Measurement of Horizontal Angles:**

## 1 Repetition Method

### Errors eliminated by this method:

- Errors due to eccentricity of verniers are eliminated by reading both verniers.
- Errors due to inadjustments of line of collimation and trunnion axis are eliminated by taking both face readings.
- Errors due to inaccurate graduations in horizontal circle are also eliminated by taking readings at different parts of the circle.
- Errors due to inaccurate bisection of object, eccentric centring etc. are eliminated due to multiple sightings of objects.

**Errors which cannot be eliminated by this method:**

- Errors due to non-verticality of vertical axis.
- Errors due to centering (slip and displacement of station signals).

**(i) Measurement of Horizontal Angles:**


## 2 Reiteration Method (or Direction Method)

- used if several angles are required to be measured at the same station.
- here, different angles are measured successively and the horizon is closed too (i.e., the angle to the first station is measured after the last station).
- Upon closing the horizon, the last reading of the vernier for the first station should match the first reading to the same station. If not, the error must be equally distributed among the measured angles.

**(i) Measurement of Horizontal Angles:**

- Set the instrument over 'O' and level it. Now set the Vernier to zero and bisect point A accurately.

- At **Face Left**, loosen the upper clamp and turn the Telescope clockwise (**swing right**) to point B. Bisect B by using the upper tangent screw. Read both the Verniers, the mean of the Verniers will give the  $\angle AOB$ .
- Similarly, bisect successively C, D and finally A, thus closing the circle. Read both the Verniers at each bisection.
- Repeat the steps in **Face Right** from A and **swing left** to sight D, C, B and back to A. The average of angles measured with Face Left and Face Right is then computed.





# Applications of Theodolite

## (i) Measurement of Horizontal Angles:

### ② Reiteration Method (or Direction Method)

A sample observation table:

Instrument at	Sighted to	Face : Left									Swing : Right				Face : Right									Swing : Left				Average Horizontal Angle		
		A			B			Mean			Horizontal Angle				A			B			Mean			Horizontal Angle						
		o	'	"	o	'	"	o	'	"	o	'	"	o	'	"	o	'	"	o	'	"	o	'	"	o	'	"		
O	A	0	0	0	0	0	0	0	0				0	0	0	0	0	0	0	0	0									
	B	54	31	20	31	20	54	31	20	AOB 54	31	20	54	31	40	31	40	54	31	40	54	31	40	54	31	40	54	31	30	
	C	102	25	40	25	40	102	25	40	BOC 47	54	20	102	26	00	26	00	102	26	00	47	54	20	47	54	20	47	54	20	
	D	239	49	40	49	40	239	49	40	COD 137	24	00	239	49	49	49	40	239	49	40	137	23	40	137	23	40	137	23	50	
	A	360	0	0	0	0	360	0	0	DOA 120	10	20	360	0	0	0	0	360	0	0	120	10	20	120	10	20	120	10	20	

## Applications of Theodolite

**(i) Measurement of Horizontal Angles:**

### 1 Reiteration Method (or Direction Method)

### Errors eliminated by this method:

- Errors due to eccentricity of verniers are eliminated by taking both vernier readings.
- Errors due to inadjustments of line of collimation and trunnion axis are eliminated by taking both face readings.
- Errors due to inaccurate graduations in horizontal circle are also eliminated by taking readings at different parts of the circle.
- Eccentricity of vertical axis is also eliminated.

**Errors which cannot be eliminated by this method:**


- Errors due to non-verticality of vertical axis.
- Errors due to centering (slip and displacement of station signals).



# Applications of Theodolite


## (iii) Prolongation of a straight line:

- 1st Method:** Set the instrument at A and sight B accurately. Establish a point C in the line of sight AB produced. Now shift the instrument to B and sight C. Establish the point D along the line of sight BC produced. Repeat the process.



- 2nd Method:** Set the instrument at B; backsight A; transit the telescope and establish a point C in the line of sight. Similarly shift the instrument to C and backsight B; transit the Theodolite to establish point D. Repeat the process.

**Note:** If the instrument is in permanent adjustment, points B, C, D, ... will be in the straight line. Otherwise, the points established shall be C', D',... which shall not be in straight line.





THANK YOU!!!